


# BGA Rework MADE FOR *SPEED!*

# Stencil<sup>TM</sup> Quik



**StencilQuik<sup>TM</sup>** – A method for decreasing BGA Rework Cycle Time

StencilQuik<sup>TM</sup> patent pending BEST Inc.

**BEST**

3603 Edison Place • Rolling Meadows, IL 60008  
v: 847.797.9250 • f: 847.797.9255

Your **BEST** choice in Solder Rework/Repair, Solder Training and Soldering Tools  
[www.solder.net](http://www.solder.net)




# StencilQuik™

## The StencilQuik™ Difference... It Stays In Place!


Are you frustrated by rework stencil printing? Are you having to perform multiple paste operations due to smeared solder paste or flux patterns? Is miniature stencil cleaning time consuming and frustrating? We have an answer to your frustrations — **StencilQuik™**. This breakthrough method allows you to simplify the placement/replacement saving 50% or more of the time required to rework BGAs or CSPs.

Whether you are using paste flux or solder paste **StencilQuik™** greatly simplifies your rework process while providing for a more reliable connection. This method features a unique stay-in-place feature which simplifies the placement while increasing the yield of reworked BGAs.


These flexible solder paste stencils remain in place on the site location becoming an integral part of the PCB assembly. **StencilQuik™** is manufactured from a polyamide film with a high temperature adhesive covered with a release liner. It is the same type of material you have been using with bar code labels and for protecting gold fingers during the wave soldering process. These stencils are laser cut from high quality, polyamide film with a residue-free high temperature adhesive backing. The **StencilQuik™** apertures correspond to the land patterns on the PCB and define those portions of the PCB which are to have paste or paste flux applied.




## How the StencilQuik™ process works




Step 1 - Prepare site



Step 2 - Align and affix the StencilQuik™ onto the PCB



Step 3 - Squeegee paste or flux through the apertures onto the PCB



Step 4 - Align, place part and reflow

Your **BEST** choice in Solder Rework/Repair, Solder Training and Soldering Tools

[www.solder.net](http://www.solder.net)

**BEST**

3603 Edison Place • Rolling Meadows, IL 60008  
v: 847.797.9250 • f: 847.797.9255

StencilQuik™ patent pending BEST Inc.